



**ALARM LOCK**

345 Bayview Avenue  
Amityville, New York 11701

For Sales and Repairs 1-800-ALA-LOCK

For Technical Service 1-800-645-9440

(Note: Technical Service is for security professionals only)  
Publicly traded on NASDAQ Symbol: NSSC

© ALARM LOCK 2011

# Trilogy Networx™ Locks DL-Windows™ QUICK START

OI362A 1/11

For a minimum wireless system, you need:

- A laptop or desktop computer to run DL-Windows™
- A wired or wireless router (to allow connection to a computer network)
- An Alarm Lock Gateway module (the intermediary device between the network and the locks)
- A Networx™ series wireless lock, powered up

If you have never used DL-Windows before, see the DL-Windows User's Guide (OI237) for basic information such as how to install and open DL-Windows, how to create Accounts, how to add Profiles to Accounts, etc. To set up a Networx wireless system, see the DL-Windows for Trilogy Networx User's Guide (OI352).

*The steps below reference pages in the DL-Windows for Trilogy Networx V4.0 User's Guide (OI352B).*

## 1. Install the DL-Windows software.

Place DL-Windows CD into the CD-ROM drive. The DL-Windows *InstallShield* Wizard will automatically begin the installation process.

## 2. Connect your computer to a Network (page 11).

## 3. Connect the Gateway to the Network (page 11).

Be sure the Gateway is NOT powered during this step.

## 4. Fill out the Gateway ID Card (blue) with the location of the Gateway.

## 5. Mount and power the Gateway module (page 13).

Horizontal "flat" mounting of the Gateway enclosure should be avoided.

## 6. Reset the Gateway (page 14).

Before securing the Gateway housing cover, press the **RESET** button on the Gateway PC board to clear the Gateway memory. *Press and hold the "RESET" button and the red light turns on continuously; continue to hold the button and the red light will start to flicker. Release the button and the red light will continue to flicker.*

Secure the Gateway housing cover with the screws provided.

## 7. Start DL-Windows and add a new Account (page 15).

## 8. Create a new lock Profile (page 15).

## 9. Add Users to the new Profile (page 16).

## 10. Click the GW Config button and enter password if prompted (page 17).



## 11. Click the Discover New Gateway(s) And Auto Add to Account button (page 18).

## 12. In the Gateway Configuration screen, click to highlight and select the Gateway, then click the Discover Locks On Selected Gateway button (page 19).

## 13. Select lock(s) by serial number and click Use Selected Locks (Page 19).

## 14. Link lock to a Profile (page 20).

In the **Link/Unlink Lock Profile(s)** screen:

- a. In the **Available Lock Profiles** field: Click to highlight the **lock Profile**.
- b. In the **Available Lock(s) By Serial Number** field: Click to highlight the **lock serial number**. Click the **Link Lock** button to save.

## 15. "Download" Profile to lock (page 21).

Check "**Send/Receive All**" and click the **Start Communication** button.

The status bar at the bottom of the window will indicate the communication progress. When communication is complete, a popup will appear. Press **OK** to close the popup, then click **Close** to close the **DL-Windows Network Lock Comm Screen**.

**Congratulations!** Locks can now be put into use and controlled wirelessly!